




Accessories

	Bracket (standard)	Basket (optional)	Beaker Positioning Cover (optional)
			
	Ideal for big parts	Ideal for small parts	For indirect beaker cleaning
for Soner 203/203H	188203-31	188203-30	188200-31
for Soner 206/206H	188206-31	188206-30	188200-31
for Soner 210/210H	188210-31	188210-30	188200-32
for Soner 220/220H	188220-31	188220-30	188200-33

Ordering Information

188203-11(22)	Soner 203, Ultrasonic Cleaner, AC110V, 60Hz (AC220V, 50Hz)
188204-11(22)	Soner 203H, Ultrasonic Cleaner (with heating function), AC110V, 60Hz (AC220V, 50Hz)
188206-11(22)	Soner 206, Ultrasonic Cleaner, AC110V, 60Hz (AC220V, 50Hz)
188207-11(22)	Soner 206H, Ultrasonic Cleaner (with heating function), AC110V, 60Hz (AC220V, 50Hz)
188210-11(22)	Soner 210, Ultrasonic Cleaner, AC110V, 60Hz (AC220V, 50Hz)
188211-11(22)	Soner 210H, Ultrasonic Cleaner (with heating function), AC110V, 60Hz (AC220V, 50Hz)
188220-11(22)	Soner 220, Ultrasonic Cleaner, AC110V, 60Hz (AC220V, 50Hz)
188221-11(22)	Soner 220H, Ultrasonic Cleaner (with heating function), AC110V, 60Hz (AC220V, 50Hz)